3Doodler

3Doodler 2.0
WARNING & NOTICE
ENGLISH

⚠ WARNING

The 3Doodler and operating rubber tip can become extremely hot. DO NOT touch the nozzle or the adjoining rubber tip. Only touch near the nozzle or the parts near the handle when changing your plastic/filament. If you accidentally get burned DO NOT allow the nozzle or the adjoining rubber tip to remain in contact with flammable materials. Allow the device to cool in the area that unit is hot and should not be touched. Do not leave the device unattended. DO NOT when not in use without warning. Also, use allow the nozzle and the adjoining rubber tip to remain in contact with flammable materials. Allow the device to cool in the area that unit is hot and should not be touched. Do not leave the device unattended.

BURN HAZARD: The 3Doodler and operating rubber tip can become extremely hot. DO NOT touch the nozzle or the adjoining rubber tip. Only touch near the nozzle or the parts near the handle when changing your plastic/filament.

FIRE HAZARD: If you accidentally get burned or smoke, cease using the unit immediately, unplug the pen, allow the pen to cool, and remove any plastic that is stuck in the nozzle. Increases the risk of fire. Do not leave the device unattended. Do not leave the device unattended.

ADULT USE ONLY: NOT INTENDED FOR USE BY CHILDREN.

WARNING: DO NOT use the 3Doodler near bathtubs, showers, basins or other vessels containing water or other liquids as death or shock may result.

The 3Doodler should only be used with 3Doodler approved filaments or materials. Use of non-approved plastics, filaments or other materials may result in damage to your unit. If you are unsure if a material is safe, please refer to the chart on the pen box, or contact support@the3doodler.com. Use of unapproved substances that are suitable for heating, or burns from filaments/materials used in the 3Doodler.

⚠ NOTICE

SNAP FINGERS ENDS!
When removing a plastic/filament from the 3Doodler, cut and remove any partially melted plastic from the tip. Failure to do so may result in damage to your 3Doodler that will reduce blockages or clogging issues.

DO NOT pull plastic/filament from the back of the 3Doodler. This will result in damage to your 3Doodler that will require repair. If you want to remove your plastic/filament, please follow the instructions on step 7.

When switching between colors of plastic/filament (such as PLA or WOOD to PLA), please purge the plastic/filament with a NEW or FLEXIBLE plastic/filament of any residual plastic/filament in the pen's heating chamber. Failure to do so may result in damage to the pen. Be sure to check for the application of a higher melting temperature plastic/filament to avoid damage to the temperature sensor.

For more information, customer service, repairs, or returns, please contact us at us@the3doodler.com

ONE TIME USE PEN

You are now the proud owner of a 3Doodler 2.0. The 3Doodler puts the power of creation in your hands, and is the world's first 3D printing pen.

#WhatWillYouCreate?
Share your creations with us on our creative, as well as tips, tricks & how-to downloadable templates, please visit our community website at **www.the3doodler.com**

GETTING TO KNOW YOUR 3DOODLER

1. Nozzle
2. Extrusion Speed Control (FAST)
3. Extrusion Speed Control (SLOW)
4. Cooling Fan
5. Power Button
6. Power Light

7. Maintenance Cover
8. Filament Guide
9. ON/OFF Switch & HOLD Button (Reverse)
10. Control Pad
11. Plastic/Filament Loader
12. Plastic/Filament
13. Nozzle Removal Tool

LED LEGEND:
Solid Light: Ready to use
Slow Blinking Light: Heating up
Fast Blinking Light: Overheating
Flashing LED: Low on plastic/filament

Actual product may vary from the image found in this document

USING YOUR 3DOODLER 2.0

Step 1: Connect your 3Doodler 2.0 to the power adapter
Connect the power adapter to the back of 3Doodler and plug it into a power source.

Note: If you have also purchased the 3Doodler_mPack™ you should connect the power pack to the back of the 3Doodler as a power source.

Step 2: Turn on the pen and select your plastic/filament
Turn the pen on by selecting the control pad corresponding to the color of the plastic/filament you are using. Make sure the slide switch (4-1) ("High") is high.

Your 3Doodler comes with a FREE sample of PLA/1.75 mm filament in WOOD, PLA/1.75 mm filament in WOOD.

Step 3: Wait for your 3Doodler to heat up before loading plastic/filament
The 3Doodler takes approximately 1-5 minutes to heat up. During this time, the LED will blink slowly. Once the 3Doodler is ready to use, the LED will be solid. If the LED is flashing quickly, it means that the pen is ready, the LED indicates when to **BLUE** (ink) or **GREEN** (ink).

BLUE = IN ("HIGH") ABS and FLEXY (heating range 210°C and 230°C or 410°F and 446°F)
GREEN = LO ("LOW") PLA (heating range between 190°C and 205°C or 374°F and 392°F)

Step 4: Load the pen
Push the plastic/filament into the back of the pen, feed it through the pen and out the nozzle. Once it is gripped by the gears inside the pen, it can take up to 30 seconds for the plastic/filament to start coming out of the nozzle. Be patient!

NOTE: If you do not feel the plastic/filament being gripped by the gears inside the pen, please give it a gentle tug to feel whether there is resistance. If there is, then the plastic/filament is loaded correctly.

Plastic/filament

Step 5: Extrude/retract your speed
Press and hold your desired speed extrusion speed (FAST or SLOW) to begin extruding plastic/filament. Release the button to stop extruding. To retract the chosen speed button will cause the pen to retract plastic/filament for up to ten seconds before loading a new color.

If the pen stops and the **RED** LED flashes, it is a sign that you need to replace the LOW plastic/filament soon. You can continue retrieving to optimize heating temperature.

NOTE: After changing plastic/filament, the 3Doodler's heating system will automatically power down. You will need to press one of the buttons (FAST/SLOW) to start heating up and then an agent to continue use.

Step 6: Switch between colors
Switch between colors of plastic/filament as needed, but because the existing plastic/filament in the pen will retain a trace left beyond the amount of plastic/filament used. Be sure to purge the pen with a piece of plastic/filament of the same color as the one you are switching to. Please see the section on Cleaning Tool, reverse the entire system as described in Step 7 (Unloading) and then load the new plastic/filament as described in Step 4 (Load the pen).

Note: For those of you who are curious, the distance between the gearbox and the nozzle is under one inch.

Plastic/filament

Step 6: Double Click for Continuous Flow

Your 3Doodler can be set to continuously extrude plastic/filament without having to hold down on the control pad. Double click the extrusion speed (FAST or SLOW) you wish to use. The LED will blink rapidly to indicate that plastic/filament flow is up to ten times before stopping.

To stop the flow of plastic/filament, simply click on either of the two buttons (FAST or SLOW).

To temporarily pause the flow of plastic/filament, hold down the button (FAST or SLOW) for 2 seconds. Release the button and then resume with a single click.

NOTE: Upon resumption of continuous flow, the extrusion temperature changes depending on which extrusion button (FAST or SLOW) you used to pause the flow. The 10 minutes limit will reset after pausing.

Step 7: Unloading/reversing your plastic/filament

Step 8: Power down
Turn the pen off by pressing the power button. Make sure the slide switch is in the "High" position.

PRO TIP: Optimize your melt time when using the slide switch (4-1). Tweak your 3Doodler's melt time by switching between the two temperature settings appropriately using the slide switch. For example, if you are using a thicker plastic/filament for up to ten minutes before switching back to thin.

NOTE: Your 3Doodler is sturdy and awesome tool, but like any mechanical device it needs a break now and then. Please allow your 3Doodler to cool down completely after 10 hours of continuous use (just a 30 minute break or so).

TROUBLESHOOTING AND CLEANING THE PEN

CLEANING TOOL: Your 3Doodler comes with a cleaning tool, stopped, or if a plastic/filament is jammed, you can use the cleaning tool to push the plastic/filament a gentle clockwise twist while pushing it down the nozzle of the pen.

If the nozzle is really clogged, you may need to remove the nozzle for a first test resistance, and being sure to do so while the pen is hot. Please see again **WARNING: BURN HAZARD** and **FIRE HAZARD!** *Be careful not to burn yourself!*

Cleaning Tool

Turn nozzle removal tool counter-clockwise

To ensure the LED light is **BLUE** or **GREEN** before starting the cleaning process.

Insert tip using the nozzle removal tool. Remove the nozzle and then the pen is hot. Please be careful not to burn yourself!

Once you have removed the nozzle, push the plastic/filament through the pen to clean out any residue. While holding down the button (FAST or SLOW), push out any excess plastic, removing it from the back of the pen.

Turn the pen off and allow it to cool down a little, but not fully. Re-insert the nozzle and tighten it. Turn the pen back on and wait for the pen to heat up. Once the LED is either blue or green, tighten the nozzle with the nozzle removal tool, stopping when the nozzle is tight. Do not overtighten. Turn the pen off and push out any excess plastic/filament that may have leaked around the nozzle using the cleaning tool.

NOTE: If you are experiencing problems extruding or suspect there may be a blockage in the 3Doodler, please remove the plastic/filament and:

A: Ensure the LED light is **BLUE** or **GREEN** before starting this process.

B: There is a metal bar inserted through the body of the 3Doodler that holds the plastic/filament in place. Please ensure that the plastic/filament is inserted between the two sides of the metal bar. Please ensure that the plastic/filament is inserted between the two sides of the metal bar.

Plastic/Filament

C: Replace the Maintenance Cover by inserting the latched end into the body of the 3Doodler. Push down on the other end of the Maintenance Cover to ensure that it is properly aligned and rests into place easily before pushing it down. Please ensure that it is properly aligned and rests into place easily before pushing it down.

WARNING: DO NOT FORCE THE BOTTOM INTO POSITION AS YOU WILL BREAK THE INSIDE PARTS OF THE 3DOODLER.

D: Once the Maintenance Cover is back in place, please ensure that the plastic/filament is still in the body of the pen while inserting the nozzle. Make sure that the Maintenance Cover fits either and. Make sure the bent end of the Maintenance Cover is inserted before the inside piece can be put (diagram).

WARNING: Never insert the metal bar the wrong way around or it will irreparably damage your pen. Use tweezers or a small metallic screwdriver to ensure the rods are in the correct position. Do not force the Maintenance Cover. If you are struggling to close the Maintenance Cover, ensure the inserted end is tucked under the lip of the body. Please ensure that the Maintenance Cover is flush with the plastic frame on the underside.

Ensure the Maintenance Cover is tucked under the lip

For a full video of how to remove and replace your plastic/filament, please visit the3doodler.com/videos

SPECIFICATIONS

Output Voltage: 5V
Output Wattage: 5W

Specifications are subject to change and improvement without notice.

CARE & MAINTENANCE

For more information, and more advice on how to maintain your 3Doodler, please see our Help Center through the3doodler.com/help

LIMITED WARRANTY

For more details on your limited warranty, please visit **threedoodler.com/warranty**

FCC NOTICE

CAN ICES-3 (B)/NMB-3(B)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Patent Pending

ADULT USE ONLY. THE 3DOODLER IS NOT A TOY FOR CHILDREN. ALWAYS USE THE PROTECTIVE GEAR PROVIDED WITH YOUR 3DOODLER.

The marking 3Doodler, 3Doodler.com, 3Doodler.com, and #WhatWillYouCreate® are trademarks owned by WobbleWorks, Inc.